

# SIRCHIE®

## FINGER PRINT LABORATORIES

### Digital Evidence Photo System

The **DEPS100** is our most complete crime/accident scene digital recording outfit is built around a full-featured, high-resolution digital camera. The camera offers many of the features you'll find on most digital cameras: aperture and shutter priority, manual and full automatic exposure, auto focus, and built-in flash with provisions for external flash. Through-the-lens images are shown on a large LCD screen that permits real-time viewing of the crime scene.



DEPS100 (above) is used to take an evidential photo of a tire track (resultant photo shown below).



Rounding out the system are evidence marking tents and placard holders. The Universal Evidence Photo Stand (shown in use to the left) is ideal for recording impression evidence as well as many other items of forensic interest. The MiniPod is included for use in close-up shots of fingerprints, tool marks and small items of evidence.

A metric version of this system is available by ordering **No. DEPS100M**.



CAT. NO.	DESCRIPTION	PRICE
DEPS100	Digital Evidence Photo System with UPS100 (w/English Scales)	\$1,495.00
DEPS100M	Digital Evidence Photo System with UPS100M (w/Metric Scales)	\$1,495.00

# PHOTOGRAPHY STANDS



Additional mounting holes are provided to permit repositioning for cameras with mounts that aren't in direct line with the lens.



DEPS102 in use with a digital camera for evidential photo (camera not included).



The flexibility of the FLXP100 accommodates a variety of surfaces. For highly irregular areas (as shown below), FLXP101 leg extenders are available.



## Universal Photo Evidence Stand

The **UPS100** outperforms cumbersome photographic tripods—no tripod legs showing up in photos and full-length photo scales are built-in on all four sides.

The frame is constructed of heavy duty steel. Polished steel is used for photo scale mounting and it features an adjustable extension arm with quick-release, professional-duty camera-type mount. This copy stand is sturdy enough to support most digital and analog (film-type) cameras up to 2.5 lbs. (1.1kg) and for convenient storage, the entire unit disassembles in seconds.

Here's the ideal companion for photographing impression evidence and other items as well. The evidence scales are printed on magnetic strips for easy replacement. The top and bottom scales adjust the full length of the frame assuring accurate measurements. **UPS100** includes one (1) set of White English Magnetic Scales (UPS101W); **UPS100M** comes with UPS102W White Metric Magnetic Scales.

## MiniPod Close-Up Stand

Lightweight, yet rugged aluminum construction, and a self-contained close-up lens make the **DEPS102** MiniPod the perfect companion for photographing small items of evidence.

Legs are easily removed for convenient storage in your camera accessory bag. The close-up lens offers edge-to-edge sharpness. A 52mm coupling fits most lenses, but adapters may be purchased for other lens sizes.

## FlexOpod™

The **FLXP100** is a compact, simple-to-use photographic platform with fully adjustable, vinyl covered, gooseneck legs to accommodate flat and irregular surfaces. Sturdy enough to support most 35mm, medium format, and digital cameras.

For situations where highly irregular surfaces such as stairwells are to be photographed, optional **FLXP101** leg extenders are available.



No need to disassemble the FLXP100, simply collapse the legs as shown above.

CAT. NO.	DESCRIPTION	PRICE
UPS100	Universal Evidence Photo Stand w/1-set of White English Scales UPS101W	\$249.50
UPS100M	Universal Evidence Photo Stand w/1-set of White Metric Scales UPS102W	\$249.50
UPS101W	White English Magnetic Scales, set of 4	\$5.95
UPS102W	White Metric Magnetic Scales, set of 4	\$5.95
UPS101B	Black English Magnetic Scales, set of 4	\$5.95
UPS102B	Black Metric Magnetic Scales, set of 4	\$5.95
DEPS102	MiniPod Close-Up Stand	\$196.50
FLXP100	FlexOpod™	\$192.00
FLXP101	Optional FlexOpod™ Leg Extenders (3)	\$96.00